

PERF	INSP

- a) The **DO NOT CLIMB** and **DO NOT DESCEND** resolution advisory.

17. At the conclusion of the test, verify the synthesized voice announcement "**TCAS TEST PASS**".

4.4 TCAS FUNCTIONAL TEST


WARNING: ENSURE THAT GROUND LOCKS ARE INSTALLED ON ALL OF THE LANDING GEAR BEFORE MOVING THE LANDING GEAR CONTROL LEVER.

- 1. Install ground locks on the nose and main landing gear per the 737-300/400/500 Aircraft Maintenance Manual 32-00-01/201.

Note: Refer to the Aeroflex IFR 6000 Operation Manual for detailed information on setup.

- 2. Mount the directional antenna to the IFR 6000 friction hinge.
- 3. Connect the directional antenna to the IFR 6000 using the short coaxial cable.
- 4. Position the IFR 6000 directional antenna as follows:
 - a) Facing the nose of the airplane.
 - b) Aligned with the airplane center line (0° relative bearing).
 - c) Above and approximately 50 feet (15.24 meters) or greater away from the top TCAS antenna.

Note: Ensure there are no obstructions between the IFR 6000 directional antenna and the airplane top TCAS antenna.

- 5. Perform the following on the IFR 6000:
 - a) Press the  key.
 - b) Press the **SETUP** control key several times until the **SETUP-TCAS** screen is displayed.
- 6. Using the **NEXT PARAM** and **PREV PARAM** soft keys on the IFR 6000, select the following:
 - a) Select **RF PORT**: set to **ANTENNA**.
 - b) Select **ANT RANGE**: set to, the distance from the IFR 6000 to the airplane top TCAS antenna.
 - c) Select **ANT HEIGHT**: set to, the height the IFR 6000 is above the airplane top TCAS antenna.
 - d) Select **UUT ADDRESS**: set to **AUTO**.
 - e) Select **ANT CABLE LOSS**: set to, the loss labeled on the coaxial cable connected to the IFR 6000.
 - f) Select **ANT GAIN (dBi)** set to the **1.03 GHz**: and **1.09 GHz**: labeled on the IFR 6000 directional antenna.
 - g) Select **SQUITTERS**: set to **ON**.
 - h) Select **ALT REPORTING**: set to **ON**.
 - i) Select **DISPLAYED ALT**: set to **ABSOLUTE**.
 - j) Select **TEST SET AA**: set to **A92493**.
- 7. Press the **TCAS** mode select key on the IFR 6000 to display the **TCAS** test screen.